

PREempt PROTOCOLS

INFECTION CONTROL PROTOCOL - PROFESSIONAL TOOLS



Cleaning Stage

ALL TOOLS (hard plastics/ hard metals) MUST BE CLEANED BEFORE BEING STERILIZED.

- In a clean sink or bowl, mix *PREempt WASH* with warm water (1:128).
- Using a brush, scrub tool clean by thoroughly removing any dirt or organic matter.
- Remove from water and thoroughly dry with disposable paper towel.

Disinfecting Stage

- Place the dry tool in an implement soaker containing *PREempt CS20*.
- LEAVE TOOL SOAKING FOR 20 MINUTES.
- Do not remove tool before 20 minutes.
- Do not leave tool soaking for longer than 20 minutes.
- Remove tool from soaker and rinse with water.
- Wipe dry with disposable paper towel. Discard used paper towel.
- Store tool in a clean and disinfected area prior to use.
- 14 Day Re-use
- **DO NOT** DILUTE CS20

TOOLS ARE NOW CLEAN & STERILIZED

