

10oz / 0.3L Drum Hand Pump for 55G / 200L Concentrates

Virox Product Code: HDP002
Case Specs: 1x1



The 10oz / 0.3L Drum Hand Pump is ideal for use with **AHP[®] Concentrate** 55G / 200L drums. See the **AHP[®] Concentrate** dispensing chart for more detailed information.

Directions for Use:

1. Attach hand pump to 55G / 200L drum by twisting it onto the bottleneck.
2. Bring your bottle or bucket of the appropriate measured amount of water under the hand pump.
3. Press down on the handle of the hand pump to release the concentrated liquid into the bottle or bucket*.
4. Follow the use directions on the 1G / 4L concentrate bottle to determine how to effectively create the In-Use Solution.

Dilution Reference Chart:

| <i>Dilutions</i> | <i>Per 5G/20L of Water</i> |
|------------------|----------------------------|
| 1:16 | 40oz/1.2L |
| 1:32 | 20oz/0.6L |
| 1:40 | 16oz/0.5L |
| 1:64 | 10oz/0.3L |
| 1:128 | 5oz/0.15L |

OTHER PRODUCTS AVAILABLE

SPRAYER FOR 32oz / 1L BOTTLE

Virox Product Code: CAP046

32oz / 1L EMPTY BOTTLE

Virox Product Code: CON025

Test strips and workplace labels are available.

*NOTE: If dripping occurs, hold bottle below the spout until dripping ceases or use a cloth or wipe to remove the excess liquid