

# PREempt®

Concentrated One-Step  
Surface Cleaner and  
Disinfectant formulated

with **ACCELERATED®**  
HYDROGEN PEROXIDE  
Patented



Concentrate

Ideal for Cleaning and Disinfection of Pedicure Foot Baths.

## WHY CHOOSE PREempt™?

- **CLEANER** Effective disinfectant as well as a cleaner resulting in added confidence that disinfection can occur.
- **FASTER** Rapid and realistic contact times on a broad spectrum of difficult to kill pathogens.
- **RESPONSIBLE** Designed to be easier on surfaces, staff and occupants. Users are not exposed to VOCs (volatile organic compounds) and Personal Protection Equipment (PPE) is not required for in use solutions as per health & safety rating.
- **SUSTAINABLE** The active ingredient, Hydrogen Peroxide, breaks down into water and oxygen leaving no active residues which helps to reduce environmental impact.

## DIRECTIONS FOR USE

Use Dilutions Made Easy

RATIO	PER 1 LITRE OF WATER	PER 4 LITRES OF WATER
1:40	25mL	100mL
1:128	8mL	32mL

### For Use to Clean and Disinfect Barber and Beauty/Manicure Instruments and Tools:

Dilute at 25ml of product per 1 Litre of water (1:40).

1. Pre-clean heavily soiled items.
2. Completely immerse pre-cleaned combs, brushes, scissors, clipper blades, razors, manicure implements and other non-porous instruments in the solution so that surfaces remain wet for five (5) minutes.
3. Rinse surfaces thoroughly and let air dry before reuse.
4. Change solution daily or when visibly dirty.

**NOTE:** Remove instruments after five (5) minutes. Then rinse, dry and keep in a clean, non-contaminated receptacle until use. Prolonged soaking may cause damage to instruments.

*For use in spas, esthetic schools, hair and nail salons, tanning salons, tattoo parlors, massage therapy centres and other critical environments that require cleaning and surface disinfection. This includes foot baths, work stations, counter tops, chairs, spa and salon equipment and other hard non-porous environmental surfaces.*



## AVAILABLE PRODUCTS

PREempt™ Concentrated One-Step Surface Cleaner and Disinfectant

**DIN:** 02436701

**SHELF LIFE:** 24 Months, 30 Days Diluted

**CONCENTRATION OF ACTIVE:** 7% Hydrogen Peroxide (Concentrated)

**Format Size:** 4 L Bottle

**Product Code:** 11305

**Packaging Specifications:** 4x4 L

### For Disinfecting Circulating Foot Baths After Each Client or Patient:

1. Drain water from basin and remove visible debris
2. Fill the basin with clean water, add the appropriate amount of diluted PREempt™ Concentrate.
3. Allow the foot bath to circulate with diluted PREempt™ Concentrate for the 5 minute contact time.
4. Drain and rinse with clean water

### For Daily Disinfection of Circulating Foot Baths:

1. Drain water from basin and remove visible debris
2. Remove filter screens, jets, and all other removable parts from the basin. Using a brush, clean any debris trapped debris with soap or disinfectant
3. Rinse the removed parts with clean water and place back into the basin
4. Fill the basin with clean water, add the appropriate amount of diluted PREempt™ Concentrate.
5. Allow the foot bath to circulate with diluted PREempt™ Concentrate for the 5 minute contact time.
6. Drain and rinse with clean water

## EFFECTIVE AGAINST A BROAD-SPECTRUM OF BACTERIA, VIRUSES AND FUNGI IN 5 MINUTES!

### Virucidal: 5 Min. (1:40 dilution)

- Poliovirus Type 1, Sabin strain type 1 which allows for a Broad-Spectrum Virucide claim against most enveloped and non-enveloped viruses
- HIV-1 Human Immunodeficiency virus (HIV)
- Human Coronavirus 229E
- Feline Calicivirus, F9 Strain, as a surrogate for Norwalk and Norwalk-like viruses
- Effective against Poliovirus and is expected to inactivate all Influenza A viruses including 2009 (H1N1) pandemic Influenza A virus

### Bactericidal: 5 Min. (1:40 dilution)

- *Staphylococcus aureus*
- *Pseudomonas aeruginosa*
- *Salmonella enterica*
- *Methicillin-resistant Staphylococcus aureus (MRSA)*
- *Vancomycin-resistant Enterococcus faecalis (VRE)*

### Fungicidal: 5 Min. (1:40 dilution)

- *Trichophyton mentagrophytes*

### Tuberculocidal: 5 Min. (1:40 dilution)

- *Mycobacterium terrae*

### Broad-Spectrum Sanitizing: 30 Sec. (1:128 dilution)

- *Staphylococcus aureus*
- *Pseudomonas aeruginosa*
- *Salmonella enterica*
- *Klebsiella pneumoniae*
- *Escherichia coli O157:H7*
- *Campylobacter jejuni*



*PREempt™ Concentrate  
One-Step Surface Cleaner and  
Disinfectant In-Use Solutions  
were designed to be easier on  
staff and occupants with half  
the contact time compared  
to traditional bleach products.*

*\*Please refer to reference sheet for a complete list of pathogenic organisms, additional features, and claims.*

*PREempt™ brand products are manufactured by Virox Technologies Inc.*

*Accelerated Hydrogen Peroxide® and PREempt™ are registered trademarks of Virox Technologies Inc.*



For more information on this or our other products, visit:

**> viroxprobeauty.com**

2770 Coventry Road, Oakville, ON CANADA L6H 6R1  
1-800-387-7578 | [www.viroxprobeauty.com](http://www.viroxprobeauty.com)



*Engineering Revolutionary Disinfectants for the War Against Microbes*